

# SL-1311-MA/B

# High Intensity 1Wx4 Blue LED Module Manual



## **SL/**° SECO-LARM°

### Features:

- 4 High intensity 1-watt LEDs
- 23 Different programmable flash patterns
- Operating life rated 100,000 hours
- Synchronize up to 20 units
- Waterproof (IP67) and vibration-resistant
- Flexible input power (10~30 VDC)

## Parts List:

High Intensity 1W LED Module	x1
Mounting screws	x2
Rubber gasket	x1

Mounting flange .....x1 Manual ......x1

### Introduction:

The ENFORCER **SL-1311-MA/B** is a High Intensity 1Wx4 LED Module strobe light that features next generation LED technology with four 1-watt LEDs in a very compact package.


This strobe light offers 23 selectable flash patterns, potted circuitry to be waterproof (IP67) and vibration-resistant, multi-unit synchronization (simultaneous or alternating), and 10~30 VDC operating voltage, making it excellent for a wide range of security and informative applications.

## Specifications:


Have been also and	Destaurulau			
Housing shape	Rectangular			
Number of LEDs	4 High intensity 1W LEDs			
Current draw*	560mA@12VDC / 300mA@24VDC			
Operating voltage	10~30 VDC			
Electrical protection	Reverse polarity protected			
Operating life	LEDs rated at 100,000 hours (>11 years)			
Number of flash patterns	23 (programmable)			
Synchronization	Simultaneous or alternating up to 20 units			
IP Rating	IP67			
Operating temperature	-22°~150° F (-30°~65° C)			
Dimensions	4 <sup>13</sup> / <sub>16</sub> "x1 <sup>5</sup> / <sub>8</sub> "x1 <sup>1</sup> / <sub>8</sub> " (122x41x29 mm)			
*Figures shown are maximums. Current draw will yary depending on flash nattern				

\*Figures shown are maximums. Current draw will vary depending on flash pattern.

## Dimensions:



### Wiring and Installation:



#### Wiring the strobe:

- 1. Black wire: Connect to power supply negative (-) terminal or ground.
- 2. Red wire: Connect to power supply positive (+) terminal 10~30 VDC. **NOTE:** It is recommended to fuse each unit @ 1A.
- 3. Yellow wire:
  - **Programming Flash Patterns**: Connect an optional SPST momentary switch such as ENFORCER SS-032Q to program the strobe light flash patterns. See connection diagram above, and **Flash Patterns** on page 4 for more instructions.
  - Synchronizing Multiple Units: Connect the yellow wires of multiple units to synchronize their flash patterns.

NOTE: All units must be set to the same flash pattern.

- Connect the yellow wires of additional units to synchronize up to 20 strobes.
- 4. White wire (optional to set alternating flash):
  - Alternating Flash: Strobes can synchronize in an alternating flash pattern. For example, when Strobe A flashes ON, Strobe B will flash OFF, etc. Synchronize all strobes. Connect the white wire to the power supply only for strobes that should alternate with the others.

#### Mounting the strobe:

- 1. Choose a mounting surface and drill a hole large enough to allow strobe wires to pass.
- 2. Feed the wires through the hole in the rubber gasket and the mounting surface.
- 3. Place the mounting flange over the LED module. Check that it is properly seated on the rubber gasket and that the gasket and mounting surface form a seal to maximize weather resistance.
- 4. Align the holes in the gasket and flange and use the self-tapping screws to secure unit in place.

#### Mounting Accessories: (not included)

SL-1311SM: Replacement plastic mounting flange for SL-1311-MA/B.

#### Flash Patterns:

- 1. LEDs are grouped into two sets, Set 1 and Set 2. The left pair of LEDs are Set 1; right pair of LEDs are Set 2.
- To change patterns, momentarily connect the strobe's yellow wire to +VDC: Each connection to power will move to the next pattern.
  Hint: Use a programming switch (not included)—see Wiring and Installation on page 3.
- 1. After changing, the flash pattern will first run one time, pause, then begin repeating.
- 2. Internal memory will retain last setting when power is disconnected.

Pattern #	Flash pattern	Pattern #	Flash pattern	
1	Single (2Hz)	4	Quad (2Hz)	
2	Double (2Hz)	5	Randomly cycles all patterns	
3	Triple (2Hz)			
Alternates between Set 1 LEDs and Set 2 LEDs				
6	Single flash each set	10	Rapid flash with fast alternation	
7	Double flash each set	11	Ultra rapid flash with slow alternation	
8	4x flash each set	12	Pattern 6 / Pattern 8	
9	5x flash each set	13	Pattern 6 / Pattern 10	
All LEDs light together				
14	Single flash	18	Rapid flash	
15	Double flash	19	Bursts of ultra rapid flash	
16	4x flash	20	Pattern 14 / Pattern 16	
17	5x flash	21	Pattern 14 / Pattern 18	
Other				
22	Set 1 steady ON; Set 2 double flash	23	All LEDs steady ON	

**California Proposition 65 Warning:** These products may contain chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to <u>www.P65Warnings.ca.gov</u>.

**WARRANTY:** This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair, or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship.

The sole obligation of SECO-LARM, and the purchaser's exclusive remedy, shall be limited to replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damages of any kind to the purchaser or anyone else.

**NOTICE:** The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors. Copyright © 2021 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

#### SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Tel: 800-662-0800 / 949-261-2999 Fax: 949-261-7326

Website: www.seco-larm.com