SECO-LARM™

Electromagnetic Gate Lock Weldable Brackets

E-942F-600G/WQ E-942F-1K2G/WQ

Installation Manual



E-942F-1K2G/WQ shown

- · For most types of outdoor sliding and swinging electric gates
- Includes brackets for armature and magnet
- Can be welded or bolted directly to gate
- Brackets are zinc-plated for corrosion resistance
- Mount vertically or horizontally
- Bracket dimensions
 - E-942F-600G/WQ Maglock $-8"x^{7/}_{16}"x^{111}/_{16}"$ (203x11x43 mm) Armature $-7^{7}/_{16}$ " $x^{7}/_{16}$ " $x^{111}/_{16}$ " (188 $x^{11}x^{43}$ mm)
 - F-942F-1K2G/WQ Maglock $-8^{1}/8$ "x $^{7}/_{16}$ "x $2^{1}/_{2}$ " (207x11x64 mm) Armature $-7^3/8$ "x $^7/16$ "x $1^{11}/16$ " (188x11x64 mm)

Model	Mounting	Compatible locks
E-942F-600G/WQ	Face	E-942FC-600AR E-942FC-600Q
E-942F-1K2G/WQ	Face	E-942FC-1K2AR E-942FC-1300

Parts List

1x Maglock bracket

1x Manual 1x Armature bracket





Installation

Before starting installation, reviewing the *Mounting Diagram* on the back of this page.

- 1. Mount the electromagnet. In most cases, the position of the electromagnet will determine the location of the armature plate. Make sure there is space to run the cable.
 - Tack weld bracket into place. a.
 - Weld 3 or 4 beads about 1" apart.
 - Mount the electromagnetic lock.
- 2. Mount the armature.
 - Once the electromagnet is mounted, determine the armature bracket location and tack weld into place.
 - h. Weld the armature bracket with 3 or 4 beads about 1" apart. Make sure not to weld near the set screw hole. (See mounting diagram for "No Weld" areas).
 - C. Mount the armature.
 - Put one rubber washer between two steel washers and place them over the armature screw between the armature and the bracket. This will allow the armature to pivot slightly around the armature screw to compensate for gate misalignment.
 - Make sure the guide pins are inserted into guide holes to prevent the armature from spinning.
 - Do not overly tighten the armature against the bracket. The armature must be able to pivot around the armature screw.

Mounting Diagram





IMPORTANT: Users and installers of this product are responsible for ensuring that the installation and configuration of this product complies with all national, state, and local laws and codes. SECO-LARM will not be held responsible for the use of this product in violation of any current laws or codes.

California Proposition 65 Warning: These products may contain chemicals which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer. SECO-LARMs obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or properly damage of any kind to the purchaser or anyone else.

NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2023 SECO-LARM U.S.A., Inc. All rights reserved.

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Phone: (949) 261-2999 | (800) 662-0800 Website: www.seco-larm.com Email: sales@seco-larm.com Order Part# 764-048%
MI E-942F-xxxGWQ 230627.docx