

## Passive Proximity Immobilizer

### SLI 762PP-ISS

The SLI 762PP-ISS Passive Proximity Immobilizer combines high security with completely passive arming and disarming. Just attach the mini controller to the key chain. Each time the driver turns the ignition on to start the engine, the Immobilizer automatically reads the controller, disarms the system, and allows the vehicle to start.

#### Features:

- Fully automatic arming 30 seconds after ignition is turned off.
- Simple disarming. Immobilizer automatically reads Controller when starting ignition. No buttons to push.
- Immobilization of up to 3 electrical circuits (e.g. starter, ignition, fuel pump) once system is armed.
- 2 Built-in 30-Amp relays and 1 transistor output.
- 2 Controllers supplied with each unit. Up to 4 controllers can be learned with simple code learning procedure.
- Each controller has millions of possible code combinations.
- Unique security code for override if controller is lost or stolen.
- The flexible sensing coil can be mounted in many positions to make installation easier.
- LED flashes to indicate Immobilizer is armed, disarmed, or triggered.
- Stealth installation—all black wires to help prevent tampering.
- All code information is stored in non-volatile EEPROM memory to protect data in case of power loss.
- Multiple car operation—One controller can work with multiple vehicles.



#### Passive Operation:

The Immobilizer automatically detects the controller and disarms the vehicle for use.



#### Specifications:

Operating voltage	9-15 VDC
Current draw (standby)	10mA@12VDC
Current draw (active)	230mA@12VDC
Number of Relays	2
Relay rating	30A@12VDC
Operating temperature	-40°~185 °F (-40 °~85 ° C)

#### Built-in Multifunction LED:

Indicates arming, armed, disarmed, and triggered modes.

Status	LED indicator
Arming	Fast Flash
Armed	Slow Flash
Disarmed	Off
Triggered	On

#### SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606

Phone: (949) 261-2999 | (800) 662-0800 Fax: (949) 261-7326


Website: [www.seco-larm.com](http://www.seco-larm.com) Email: [sales@seco-larm.com](mailto:sales@seco-larm.com)

Copyright 2015 © SECO-LARM U.S.A., Inc. All rights reserved. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. The SECO-LARM policy is one of continual development. For that reason, SECO-LARM reserves the right to change prices and specifications without notice. SECO-LARM is not responsible for misprints.

SECO-LARM® ENFORCER® CRIMEBUSTER® CBA SLI®

PI\_SLI762PP-ISS\_150811.docx

## Wiring Diagram:



**SECO-LARM® U.S.A., Inc.**

16842 Millikan Avenue, Irvine, CA 92606

Phone: (949) 261-2999 | (800) 662-0800 Fax: (949) 261-7326

Website: [www.seco-larm.com](http://www.seco-larm.com) Email: [sales@seco-larm.com](mailto:sales@seco-larm.com)

Copyright 2015 © SECO-LARM U.S.A., Inc. All rights reserved.  
 All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners.  
 The SECO-LARM policy is one of continual development. For that reason, SECO-LARM reserves the right to change prices and specifications without notice. SECO-LARM is not responsible for misprints.

**SECO-LARM® ENFORCER® CRIMEBUSTER® CBA SLI**

PI\_SLI762PP-ISS\_150811.docx