

## Touchkey Immobilizer

### SLI 762FP-ISS

*The SLI 762FP-ISS Touchkey Immobilizer combines high security with the convenience of completely passive arming. To arm, turn off the ignition. 30 seconds later, up to two of the car's electrical circuits are disabled. To disarm the system, insert the Touchkey momentarily into the Touchkey receptacle. You now have 30 seconds to start your vehicle or the Immobilizer will rearm.*

#### Features:

- ▶ Fully automatic arming 30 seconds after ignition is turned off.
- ▶ Disarm by inserting Touchkey into Backlit Receptacle.
- ▶ Immobilization of up to two electrical circuits (e.g. starter, ignition, fuel pump) once system is armed.
- ▶ Two built-in 30-Amp relays.
- ▶ Two Touchkeys supplied with each unit. Up to 4 Touchkeys can be learned with a simple code learning procedure.
- ▶ Each Touchkey has millions of possible code combinations.
- ▶ Unique security code to override if Touchkey is lost or stolen.
- ▶ Stylish Backlit Receptacle for easy use and operation at night.
- ▶ LED located in Backlit Receptacle flashes to indicate immobilizer is armed, disarmed, or triggered.
- ▶ Mini tamper-proof housing with all black wires helps prevent the disabling of system by thieves.
- ▶ EEPROM stores codes for up to one year if power is lost.
- ▶ Multiple car operation: One Touchkey can control all vehicles.



#### Passive Operation

*To exit the car, turn the engine OFF. 30 seconds later, the red LED starts flashing. The Immobilizer is armed and up to two of the car's electrical circuits (starter, ignition, fuel pump) are disabled.*

#### Specifications:

Operating voltage	10~15 VDC
Current draw (standby)	5mA@12VDC
Current draw (active)	230mA@12VDC
Number of relays	2
Relay rating	30A@12VDC
Operating temperature	-40°~185° F (-40°~80° C)

#### Built-in Multifunction LED:

*Indicates armed, disarmed, and triggered modes.*

Status	LED indicator
Armed	Flashing
Disarmed	Off
Triggered	On

