

4-in-1 HD Video Distributors Manual



Features:

- TVI / CVI / AHD / Analog compatible
- Distributes one video input to two (or four*) video outputs
- Connect to a video camera, multiplexer, DVR etc.
- LED power indicator
- Signals are cleaned and buffered to ensure clear video over the camera's recommended maximum distance

* VA-1104B-WYQ - special order only

SECO-LARM[®] **SL/**[®]



ENFORCER 4-in-1 HD Video Distributors

Introduction:

ENFORCER 4-in-1 HD Video Distributors are the ideal way to distribute a single video signal to multiple locations. Using noise-rejection circuitry, the 4-in-1 HD Video Distributors actively duplicate video signals to be sent to either two (or four*) separate locations. The distributors buffer incoming signals before duplication for clean transmission.

* VA-1104B-WYQ - special order only

Parts List:

1x 4-in-1 HD Video Distributor	1x Manual	1x Power adapter	1x DC Jack connector
2x Mounting screws	2x Plastic wall anchors	4x Mounting screws	4x Plastic wall anchors
(VA-1102B-WYQ)	(VA-1102B-WYQ)	(VA-1104B-WYQ)	(VA-1104B-WYQ)


Specifications:


Model	VA-1102B-WYQ	VA-1104B-WYQ*	
Number of inputs	1x BNC		
Number of outputs	2x BNC	4x BNC	
Video output format	HD-TVI / CVI / AHD / Analog		
Video input level	0.8~1.2Vp-p, 75Ω		
Video output level	1Vp-p, 75Ω		
Image gain	6dB		
Video bandwidth	350MHz, -3dB		
Power supply	12VDC, 500mA		
Current draw	60mA	220mA	
Operating humidity	0~95% non-condensing		
Operating temperature	32°~131° F (0°~55° C)		
Dimensions	2 ⁵ / ₁₆ "x1 ¹⁵ / ₁₆ "x1 ¹¹ / ₁₆ " (58x49x42 mm)	5 ⁷ / ₁₆ "x3 ³ / ₈ "x1 ³ / ₁₆ " (138x86x30 mm)	
Weight	2.5-oz (70g)	4.9-oz (140g)	

* VA-1104B-WYQ - special order only

Overview:

VA-1102B-WYQ shown






Installation:

- 1. Place the 4-in-1 HD Video Distributor where the video inputs and outputs can be easily accessed.
- 2. Plug the male BNC connector into the input female BNC connector on the distributor.
- 3. Plug the male BNC connectors into the output female BNC connectors on the distributor.
- 4. Connect power to the distributor with the included 12VDC power adapter and DC jack connector.
- 5. Turn on power to the displays and the video output unit the distributor is connected to.


NOTE: Maximum distance between the camera and DVR/monitor is determined by the camera's recommended maximum distance.

Sample Application (VA-1102B-WYQ):



Max. range between camera and monitor determined by camera's max. distance

Sample Application (VA-1102B-WYQ Stacking):



determined by camera's max. distance

Troubleshooting:

4-in-1 HD Video Distributor does not function correctly	 Make sure the power, input and output cables are connected firmly to the distributor Make sure the video input device is turned on Make sure the video output device is turned on Test the coaxial cable between the video source and the distributor to make sure it is functional Test the coaxial cable between the video display and the distributor to make sure it is functional 			
Power LED indicator not lit	Make sure power is connected to the distributor			
Also Available from SECO-LARM [®] :				
4-in-1 HD Video Amplifier	4-in-1 HD Surge Protector	4-in-1 HD Ground Loop Isolator		
VA-2102B-WYQ	VS-1V12YQ	VG-1C12YQ		
Passive HD Video Balun	Endpoint HD VPD Combiner	BNC to VGA Converter		
		and the second s		
EB-P101-01HQ	EB-C304-01EQ	VC-3BAQ		

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT: Users and installers of this product are responsible for ensuring this product complies with all national, state, and local laws and statutes related to monitoring and recording audio and video signals. SECO-LARM will not be held responsible for the use of this product in violation of any current laws or statutes.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for one (1) year from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.

NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2017 SECO-LARM U.S.A., Inc. All rights reserved.

SECO-LARM[®] U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Phone: (949) 261-2999 | (800) 662-0800

Website: www.seco-larm.com Email: sales@seco-larm.com

