

VC-3YAQ

4-in-1 HD to HDMI Converter

Manual





Features:

- Converts HD-TVI, HD-CVI, HD-AHD, or Analog/CVBS video to HDMI, VGA, CVBS, or loop output
- Secondary BNC connection supports CVBS conversion, loop output, or dual HD Analog video input
- Dual HD Analog video input mode to switch between multiple video inputs
- Wall mountable with included screws

SECO-LARM[®] **SL/**[®]

- Picture-in-picture mode when dual HD Analog video input used
- HDMI/VGA output support: 480p, 576p, 720p, 1080i, 1080p
- CVBS output support: NTSC, PAL
- CVBS underscan adjustment
- Compact, perfect for plug and play installations
- Quick installation, no driver or operating system requirements



ENFORCER 4-in-1 HD to HDMI Converter

Introduction:

The SECO-LARM 4-in-1 HD to HDMI Converter is the ideal way to transform HD-TVI, HD-CVI, HD-AHD, or traditional analog video inputs into an HDMI, VGA, or CVBS signal. The converter also allows for HD Analog video loop output, HD Analog dual video input, and picture-in-picture modes. The HD to HDMI Converter is compact and can be mounted nearly anywhere. The HD to HDMI Converter is perfect for converting any HD Analog video source to an HDMI, VGA, or CVBS signal to allow viewing on a wide range of video monitors.

Parts List:

1x Converter

1x 12VDC power adapter

1x Manual


- 4x Wall mount screws
- 4x Wall mount screw anchors

IX IVIAIIUA

Specifications:

•			
Input signal		HD-TVI, HD-CVI, HD-AHD, NTSC, PAL	
Output signal		HDMI, VGA, CVBS, loop output	
Input resolutions supported		720p@25/30/50/60 Hz, 1080p@25/30 Hz, NTSC, PAL	
Output resolutions	HDMI/VGA	480p, 576p, 720p@50/60 Hz, 1080i@50/60 Hz, 1080p@50/60 Hz	
supported	CVBS	NTSC/PAL	
	HDMI	Type A 19-pin female	
Output connector	VGA	D-SUB 15-pin female	
	BNC	75Ω 1Vp-p	
Input connector		BNC (75Ω 1Vp-p)	
Maximum input cable length		HD-TVI, HD-CVI, HD-AHD: 984ft (300m); CVBS: 328ft (100m)	
Maximum output cable length		HDMI: 16ft (5m); VGA: 16ft (5m); CVBS: 328ft (100m)	
Power supply		500mA@12VDC	
Power consumption		350mA (max.)	
Operating humidity		Up to 95%	
Operating temperature		32°~131° F (°0~55° C)	
Dimensions		5 ¹ /8"x3 ⁷ / ₁₆ "x1 ³ / ₁₆ " (130x88x30 mm)	
Weight		9.7-oz (275g)	

Overview:



LEDs:

The VC-3YAQ has six LEDs that indicate input and output status.

HDMI Output Side			VGA	VGA Output Side		
Ρ	Green	Power input present	L	Green	Loop output mode	
S	Blue	Signal (Main Input)	S	Blue	Signal (Secondary Input)	
Н	Red	HDMI output present	С	Red	CVBS output mode	

DIP Switch Settings and Button Functions:

Output	DIP	DIP	DIP	DIP	Function Buttons		
Mode	1	2	3	4	Left 🗲	Right 🕨	Left + Right ◀ + 🕨
Loop output	OFF	OFF	OFF	OFF	Decrease output resolution	Increase output resolution	Switch AHD/CVI (requires power cycle) ¹
CVBS output	ON	OFF	OFF	OFF	Decrease CVBS underscan	Increase CVBS underscan	Switch CVBS output 4:3/16:9
Dual input	OFF	ON	OFF	OFF	CVBS Input (main)	CVBS Input (secondary)	Switch 4:3/16:9 (CVBS main input only)
PIP ² output	OFF	ON	ON	OFF	Adjust PIP positioning counterclockwise	Adjust PIP positioning clockwise	Switch PIP main source
PIP output	OFF	ON	ON	ON	Decrease PIP sizing	Increase PIP sizing	N/A


¹ If an HD-CVI or HD-AHD source is used and the image displayed is B&W then press both function buttons at the same time and power cycle the converter. Upon power up the image will display correctly. HD-TVI does not require a power cycle to output correctly. ² PIP: Picture-in-Picture (for dual inputs)

Installation:

- 1. Determine the location where the 4-in-1 HD to HDMI Converter will be installed.
- 2. Use the DIP switches to set the desired output mode.
- 3. Plug the BNC cable from the CCTV camera to the CVBS Input (Main) BNC connector on the converter.
- 4. Plug the remaining VGA, HDMI, and BNC output cables into their respective ports as necessary.
 - a. For loop output, connect the other end of the BNC output cable to the local DVR or monitor.
 - b. For CVBS output, connect the other end of the BNC output cable to the local DVR or monitor.
 - c. For dual video input, connect the other end of the BNC output cable to the secondary CCTV camera.
- 5. Plug the 12VDC adapter into the converter.
- Once all cables are routed use the included mounting screws and mounting screw anchors to permanently mount the unit.
- Use the function buttons to adjust the output resolution, CVBS underscan, picture-in-picture position, or picture-in-picture size based on the DIP switch settings.
- 8. If needed, adjust your monitor settings according to the manufacturer's instructions.

Sample Applications:

Loop Output Application:




SECO-LARM U.S.A., Inc.

ENFORCER 4-in-1 HD to HDMI Converter

Sample Applications (Continued):

Dual Input Application (Same Cable Connections Also Used for PIP):



Troubleshooting:

HDMI or VGA monitor does not display properly	 Make sure power, input, and output cables are firmly connected to the converter. Make sure the CCTV inputs are turned on. Make sure the video output devices are turned on. Test the cables between the converter and video output devices to ensure they are functional.
HDMI Output side LED not lit	 Ensure relevant connector is firmly connected.
VGA Output side LED not lit	 Ensure correct mode is selected using the DIP switches.
HD-AHD or HD-CVI outputting B&W video	 Press both function switches at the same time and reset power.

HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

IMPORTANT: Users and installers of this product are responsible for ensuring this product complies with all national, state, and local laws and statutes related to monitoring and recording audio and video signals. SECO-LARM will not be held responsible for the use of this product in violation of any current laws or statutes.

FCC COMPLIANCE STATEMENT: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for two (2) years from the date of sale to the original customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM. This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship. The sole obligation of SECO-LARM and the purchaser's exclusive remedy, shall be limited to the replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damage of any kind to the purchaser or anyone else.

NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2017 SECO-LARM U.S.A., Inc. All rights reserved.

SECO-LARM[®] U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Phone: (949) 261-2999 | (800) 662-0800 Website: www.seco-larm.com Email: sales@seco-larm.com



MI_VC-3YAQ_170515.docx