



ENFORCER Infrared Proximity Sensors FAQ

For CS-PD535-TAQ and CS-PD535-TBQ

Edited September 8, 2021

Pre-Sale Questions

Where can this be installed?

The sensor is meant to be installed on a rigid thin surface with a maximum thickness of $1/16$ " (2mm).

What is the maximum amperage for a connected device?

Do not connect any device that will exceed 3A@24VDC.

The standby LED indicator default colors are red (blue for CS-PD535TBQ), changing to green when triggered. Can I reverse the colors so that the standby color is green?

Yes. To reverse the standby color, simply remove the jumper located above the *Output Time* and *Sensor Range Trimpots*. To avoid losing the jumper, you can place it on either of the two pins but not on both.

Can I adjust the sensor's triggering range?

Yes. The default range is set to the maximum distance of 8" (20cm). To decrease the range, turn the *Sensor Range Trimpot* counterclockwise until the desired range is attained. The minimum allowable range is $2\frac{3}{8}$ " (6cm).

The trimpots are arranged vertically to the right of the terminal block and the *Sensor Range Trimpot* is on the bottom.

NOTE: Do not force the trimpots. Only minimal force is needed to turn them.

Can I adjust the trigger duration?

Yes. The default trigger duration is set to the minimum of 0.5 seconds from the factory. To increase the trigger duration, turn the *Output Time Trimpot* clockwise until the desired time is attained (up to 30 seconds). However, note that turning the *Output Time Trimpot* to its maximum position will set the trigger to *Toggle Mode* (toggling between ON and OFF).

The trimpots are arranged vertically to the right of the terminal block and the *Output Time Trimpot* is on the top.

NOTE: Do not force the trimpots. Only minimal force is needed to turn them.

Can I set the trigger to toggle ON/OFF?

Yes. To do so, simply adjust the *Output Time Trimpot* to the maximum setting using the *Output Time Trimpot*.

The trimpots are arranged vertically to the right of the terminal block and the *Output Time Trimpot* is on the top.

NOTE: Do not force the trimpots. Only minimal force is needed to turn them.

Is it possible to use this sensor as an anti-theft sensor, triggering when an object is removed from the sensor's read range instead when an object enters the sensors read range?

Yes. To serve as an anti-theft sensor, use the sensor's N.C. output instead of the N.O. output. Connect this to the alarm panel's N.C. input and the COM to the alarm panel's COM terminal.

Can I connect the sensors directly to a door strike?

Yes, but we suggest connecting a metal oxide varistor (MOV) or diode (both not included) as close as possible and in parallel with the controlled output device. Make sure that the diode's cathode (striped end) is installed toward the strike's positive terminal. This absorbs possible electromagnetic interference to prevent damaging the IR proximity sensor. See manual for further detail.

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606

Phone: (949) 261-2999 | (800) 662-0800 Fax: (949) 261-7326

Website: www.seco-larm.com Email: sales@seco-larm.com

Copyright © 2021 SECO-LARM U.S.A., Inc. All rights reserved.

All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners.

The SECO-LARM policy is one of continual development. For that reason, SECO-LARM reserves the right to change prices and specifications without notice. SECO-LARM is not responsible for misprints.

SECO-LARM® ENFORCER® CRIMEBUSTER® CBA® SLI®

FAQ_CS-PD535-PxQ_210908.docx

Are these sensors weatherproof?

These sensors are not designed for outdoor installation. SECO-LARM has a range Wave-to-Open sensors designed for weatherproof installations in $\frac{3}{4}$ " (19mm), $\frac{7}{8}$ " (22mm), and $1\frac{1}{2}$ " (38mm) diameters.

General Installation Questions

My sensor sometimes triggers unexpectedly. What could be the problem?

Due to the nature of IR technology, an IR sensor can be triggered by a direct light source such as sunlight, reflected light from a shiny object, or other direct light aimed at the sensor. Consider any possible sources of reflected or direct light and how that may be avoided. Consider a hood or some other shield to protect the sensor from such a light source.

My sensor remains triggered. What could be causing that?

Note that the sensor will remain triggered as long as something is within range. Ensure that nothing is remaining within the range of the sensor.

Reduce the IR range of the sensor (see *Can I adjust the sensor's triggering range?*).

Ensure that your sensor's *Output Time Trimpot* is not adjusted to maximum. Turning the trimpot to maximum will set the trigger to toggle mode.

Check that the power supply's voltage is correct (12~24 VDC).

My sensor will not trigger. What could be causing that?

Increase the IR range of the sensor (see *Can I adjust the sensor's triggering range?*).

Check that the power supply's voltage is correct (12~24 VDC).

How should I clean the sensor?

The sensor requires special care to ensure reliability and a long operating life. When cleaning is needed: 1) Use a soft, clean cloth (a microfiber cloth is recommended) and use the mildest cleaner available. 2) Spray the cleaning solution onto the cleaning cloth instead of the unit. 3) Wipe any excess liquid from the sensor. Wet spots may affect the sensor's performance and leave a dust ring when they dry.