

FOLD ON DOTTED LINE


TEMPLATE

1,200-lb Electromagnetic Lock with Bond and Door Position Sensors **E-941SA-1K2DPSQ**

SECO-LARM® www.seco-larm.com

MT E-941SA-1K2DPSQ 210318.cdr

Armature Plate Holder



INSTALLATION INSTRUCTIONS

- Fold the template along the dotted center line to form a 90-degree angle. Place the template against the door frame header
- 2. Mount the armature plate to the door using the armature plate holder, 6 screws, and the included sexnut bolt along with 1 rubber washer sandwiched between 2 steel washers. The washers are installed through the sexnut bolt and between the armature plate and armature plate holder.
- 3. Install the mounting plate with 2 flathead screws through the slotted adjustment holes
- 4. Adjust the mounting plate so it forms a right angle with the armature plate. Using the mounting plate as a template, drill the wire hole and install the remaining mounting screws
- Do not photocopy this template as photocopiers alter dimensions

- 5. Install the magnet to the mounting plate with the 2 Hex head mounting screws supplied
- 6. Install the electrical wiring per the manual and wiring diagrams
- 7. Test and confirm all functions of the magnetic lock are working. For further installation instructions, see the user manual